

Update to version 3.0

Please note:

- Your user-defined programs and settings will not be overwritten by the update.
- Prerequisite for the update is at least Trikombin Version 1.3.
- The update should only be carried out if the batteries are charged to at least 50%. You can also perform the update while the batteries are being charged.

Installation Instructions

1. Copy the files "trikombin_os_update.4_0_0_0.7z" and "trikombin_sw_update.3_0_1_0_rep.7z" into the root directory of a USB stick. The root directory should not contain any other files that end with ".7z".
2. Insert the USB stick into the appropriate socket on the Trikombin device. It is located below the rotary encoder.
3. Switch the Trikombin device off and on again.
4. Wait at least 15 seconds (the Trikombin needs a few seconds to recognize the USB stick).
5. Click the "Maintenance" button on the touch screen. The "Maintenance" dialogue appears.
6. Click on "Update Firmware ...".
7. After a few seconds, the following message appears "A more recent Software version is available. Do you want to update now?". Confirm with "Yes".
8. After about 45 seconds, the unit will restart automatically. Under certain circumstances, the message "Wrong archive file" is displayed briefly.
9. Turn off the device.
10. Hold down the "Esc" key and turn the power back on. The device starts into the Maintenance mode.
11. Press key "1" or click "Update System (Key '1')".
12. After a few seconds a message is displayed. Confirm it by pressing the "Enter" key or click "Yes".
13. After some time, the message "Update finished successfully! Reboot system?" is displayed. Confirm this by pressing the "Enter" key.

Verifying the Installation

1. Click on "Maintenance".
2. The following version numbers should now be displayed:
 - Trikombin program: 3.0.0#7
 - Database: 4
 - Frequency tables: 5
 - Linux: 4

FPGA: 3.1